

# ASSEMBLY INSTRUCTIONS



### Component List











A - Phillips Screwdriver

B - Cabinet x 1

**C -** 8/32" x 12mm

x 24

Phillips Screw

x 1 (not provided)



E - Caster x 4

F - M4 x 37mm


**G** - M4 x 25mm


x 4

Phillips Screw









- I Legal File Bar x 2
- J Lateral File Bar x 1
- K Shelf Pin x 8
  - L Adjustable Printer Shelf x 1
  - M Adjustable Cabinet Shelf x 1

Designed by Matthew Weatherly. These distinctive product configurations are protected by US and international patents, trade dress, and/or copyright laws. BDI and Format are trademarks of Becker Designed, Inc. All Rights reserved. ©2012, BDI Made in Taiwan. 6320REV062012v2

## BDIUSA.COM CUSTOMERSERVICE@BDIUSA.COM

Format is engineered for easy assembly. Carefully follow this procedure to prevent any damage.

### Do not use power tools for assembly of this product.



Placement and Maintenance Format<sup>™</sup> Office furniture is designed for indoor use on level floors. Clean steel parts and wood veneer with a moist cloth.


### Step 1

### Unpack and Identify

Unpack and identify the components at left. Note that some components are shipped inside the cabinet. The assembly workspace should be a non-marring surface such as carpet. For missing hardware pieces, please contact BDI Customer Service at customerservice@bdiusa.com. For all other concerns, please contact your BDI Retailer.

#### Step 2 Install Casters

Carefully position **Cabinet (B)** on its back side so that bottom side is accessible, then attach a **Caster** at each of the six (6) exposed installation plates using **5/32" x 12mm Phillips Screw (C)** and a Phillips Screwdriver. Then carefully turn **Cabinet (B)** upright.




### Step 3

### Install Pulls.

Install Pull (H) to drawers using the M4 x 37mm Phillips Screw (F) and a Phillips Screwdriver. Install Pull (H) to door and file drawer using the M4 x 25mm Phillips Screw (G) and a Phillips Screwdriver.






#### Step 4 **Install Shelves.**

FORMAT

6320

BD


Install Shelf Pins (K) at desired height to install Adjustable Shelves (L) and (M). \*Note: To place the adjustable shelf inside the cabinet, the shelf may be tilted sideways to clear the door opening.



#### Step 5 Optional - Install File Bars

Legal File Folders can be installed in the lateral drawers left-to-right without installing File Bars.

Letter File Folders can be installed in the lateral drawer left-to-right by lowering **Lateral File Bar (J)** onto drawer sides.



If users wish to install File Folders front-to-back, place **Legal File Bars (I)** onto drawer rails front and back.

