
SEQUEL® 20 6117 MULTIFUNCTION CABINET

INSTRUCTION MANUAL

LET'S GET STARTED.



DESIGN MATTHEW WEATHERLY





Congratulations on the purchase of your Sequel 20 Multifunction Cabinet 6117 from BDI. Your file cabinet has been designed to provide a lifetime of enjoyment. This manual will provide you with assembly instructions and other helpful information that will ensure that you get the most out of your cabinet. Please save it for future reference.

Your Sequel 20 Multifunction cabinet has been engineered for simple assembly. Please follow these directions carefully to prevent any damage.

Should you need further assistance, contact BDI at customerservice@bdiusa.com.





HARDWARE AND COMPONENTS


Unpack and identify the parts listed below. The assembly workspace should be a non-marring surface such as carpet. For missing hardware pieces, please contact BDI Customer Service at **customerservice@bdiusa.com**.


Do not use power tools for assembly of this product.


For all other concerns, please contact your BDI retailer.






















HARDWARE AND COMPONENTS














STEP 1. ATTACH THE LEGS




Make sure **(C4)** Adjustable Shelf is still held in place with packing material (or removed from the **(C1)** Cabinet). Carefully position **(C1)** Cabinet onto its back. Install **(C2)** Leg Frames using **(H1)** Screws and **(T1)** Hex Wrench.


PART/DESCRIPTION	ОТУ
T1-HEX WRENCH	1
H1-SCREW	16








With help from another person, carefully lift the cabinet onto its base. Place (C5) Glass Top Panel into position on top of the (C1) Cabinet. Align all edges. The glass edge should be offset 1.5mm from the side of the cabinet on all 4 sides.



STEP 3. ATTACH DRAWER PULLS

ASSEMBLY

Open a drawer and connect a (C3) Drawer Pull using 2 (H2) Screws. Tighten with a Phillips Screwdriver (not included). Install the other 2 (C3) Drawer Pulls one at a time.



	PART/DESCRIPTION	ОТУ
	H2-Screw	6
« ())	NOT INCLUDED Phillips Screwdriver	1


ADJUSTABLE SHELF

Install the **(C4) Adjustable Shelf**. You may adjust the position of the **(C4) Adjustable Shelf** by pulling the 4 shelf pins out and relocating them.

PART/DESCRIPTION	ОТУ
T2-Leveler Wrench	1


LEVEL CABINET

Make sure the **(C1) Cabinet** is level. Adjust 1 or more of the levelers using **(T2) Leveler Wrench** to attain a level stance.



For forward facing files, attach (H6) File Bar Clips to PART/DESCRIPTION QTY each end of the (H4) Small File Bars. Slide the bars onto the rails so that the (H6) File Bar Clip goes into the **groove**. H4-SMALL FILE BAR 2 For **sideways** facing files, **see below.** H5-LARGE FILE BAR 1 Н4 H6-FILE BAR CLIP 6 Н6 Legal Letter/A4 Grooves Н4

For letter files facing sideways, attach (H6) File Bar Clip to both ends of (H5) Large File Bar as shown. Place the file bar assembly in the notches located on the left and right drawer side panels. For side facing legal files, skip this step altogether and hang file folders directly on front and back rails.



CARE & MAINTENANCE

GLASS

Glass surface is maintained using household glass cleaner and a paper towel or cloth.

SATIN-ETCHED GLASS

This uniquely smooth-to-the-touch glass surface can be regularly maintained using household glass cleaner and a paper towel or cloth. Minor scratches or scuffs not eliminated using paper towel or cloth can usually be removed by using a 'Magic Eraser'. Magic Eraser is a melamine foam product available at any grocery store or home improvement center. Dampen the entire glass surface as well as the Magic Eraser, then rub the entire glass surface in broad, even strokes using moderate pressure. Clean and dry the surface with a paper towel. Check for results and repeat as necessary.

Any scratches or scuffing not eliminated by one of the above methods can often be addressed by 'refreshing' the glass. This is a process that should not be required more than once per 6-12 months. See this brief video for the simple method: www.bdiusa.com/glass

WOOD

Wood surfaces should be cleaned with a slightly damp (not saturated) cloth or paper towel. Do not use glass cleaner on wood. If moisture remains, dry the surface with another cloth. If needed, a gentle non-abrasive cleanser may be used, but be sure to wipe away all cleaner residue and dry the surface with a cloth.

BDI's wood finishes feature natural hardwood solids and veneers. Wood is a product of nature and—unlike man-made materials that can be manufactured to strict and consistent specifications—has natural imperfections that are part of its appeal and character. Every piece of wood differs from every other, even when coming from the very same tree. As such, variation in grain, texture and tone should be expected from one panel or piece of furniture to the next.

While BDI's stained wood finishes are stable in tone & appearance, all finishes are subject to some degree of discoloration with prolonged exposure to direct sunlight. Please take care to avoid positioning your BDI cabinet in any area with extensive direct sunlight. To learn more about the features of natural wood, visit **www.bdiusa.com/wood**

METAL & PAINTED SURFACES

Surfaces should be cleaned with a slightly damp (not saturated) cloth or paper towel. If moisture remains, dry the surface with another cloth. If needed, a gentle non-abrasive cleanser may be used, but be sure to wipe away all cleaner residue and dry the surface with a cloth.

BDI warrants to the original purchaser that for the below stated warranty term, BDI will repair or replace any product, part, or component covered by this warranty which fails under normal use as a result of a defect in material or workmanship. BDI will repair or replace the aforementioned product, part or component with a comparable product, part or component. The decision to repair or replace will be at BDI's sole discretion.

BDI Home Theater Furniture, Office Furniture, Modular Systems, Tables and other furniture pieces are warranted for three (3) years from the date of purchase as shown on your sales receipt. The warranty period starts from the date of purchase. This warranty extends only to the original purchasers who acquire new product from BDI Authorized Resellers. Any product, part, or component must have been assembled, installed, used, and maintained according to BDI's published instructions in order to be eligible for warranty coverage. Any modification to the original product voids the warranty.

To view BDI's complete warranty information, visit www.bdiusa.com/warranty

PRODUCT REGISTRATION

Registering your new BDI product allows us to send you important product updates, service information and helpful hints related to your BDI products. Register today, and you will be entered to win free a BINK table from BDI: www.bdiusa.com/register



SERIOUS OR FATAL CRUSHING INJURIES CAN OCCUR FROM FURNITURE TIP-OVER. TO HELP PREVENT TIP-OVER:

- Install tip-over restraint.
- Place heaviest items in lower compartments.
- Never allow children to climb or hang on drawers, doors or shelves.
- Never open more than one drawer at a time.

USE OF TIP-OVER RESTRAINT MAY REDUCE—BUT NOT ELIMINATE—THE RISK OF TIP-OVER.



These distinctive product configurations are protected by US and international patents, trade dress, and/or copyright laws. Sequel & BDI are trademarks of Becker Designed, Inc. All rights reserved. ©2020, BDI $\,\mid\,\,$ V.05.15.2020

Made in Vietnam.