


CENTROTM 6417 MULTIFUNCTION CABINET




bdiusa.com customerservice@bdiusa.com



These distinctive product configurations are protected by US and international patents, trade dress, and/or copyright laws. Centro & BDI are trademarks of Becker Designed, Inc. All rights reserved. ©2015, BDI Made in China. 02.16.2016 V2


Step 2 - Install Base

Attach Base to Cabinet using Screws H1 and tighten with Hex Wrench.




Step 3 - Adhere Bumpers H4 as shown.

Step 4 - From below the top panel, attach Glass Panel with Screws H3 using Hex Wrench.




2 **BDI** CENTRO 6417 MULTIFUNCTION CABINET bdiusa.com customerservice@bdiusa.com Step 5 - Attach Pulls to Cabinet using Screws H2 and tighten with a Phillips screwdriver.



Step 6 - File Bar Installation (Option A)

For files facing forward, attach **File Bar Clip C6** to both ends of **Small File Bar C4** as shown. For letter files, use the outer notches on the front and back of the drawer. For legal files, use the inner notches.



Step 7 - File Bar Installation (Option B)

For letter files facing sideways, attach File Bar Clip C6 to both ends of Large File Bar C5 as shown. Place the file bar assembly in the notches located on the left and right drawer side panels. For side facing legal files, skip this step altogether.

